



# STL K-Force 47\"

## SUMMARY:

With super bright Linear design and 132 powerful Generation III LEDs, the STL K-Force 47\"

- Powered by 12V
- Weather-proof housing
- Double-layer aluminum alloy board
- 132 Generation III 1-watt LEDs
- Linear optics
- LED take-down and alley lights
- Built in amber arrow stick
- Arrow stick directions: right, left, center out, and 2 center 4 out
- 15 available flash patterns
- Non-volatile memory recalls last flash pattern
- Lifespan of up to 100,000 hours
- Includes [STL Supreme Control switch box with P&P SERVICEABILITY!](#)
- Includes 13 feet of cable to switch box, 8 feet of power cable, and 8 feet of auxiliary cable
- Includes gutter brackets for mounting
- Dimensions: 47\"
- 7 day money back guarantee
- 3 year warranty!

## INSTALLATION INSTRUCTIONS:

1. Place the full light bar on the top of your vehicle and adjust it to fit your vehicle.
2. Attach the gutter mount bracket to the light bar using the bolt and tighten the bolt until your light bar is secure.
3. Once the light bar is secure, drill the bracket to the vehicle's gutter for a more secure hold.
4. Now wire up the light bar to your vehicle by connecting the light bar to your supreme control switch box.
5. Wire your power cables (the long red and black cables) to your battery to power up your light bar.

6. The red and blue cables coming from the Supreme Control box are auxiliary cables used to wire up other products to the Supreme Control switch box. **These are not power cables.**
7. Slide the slider switch to position one to power on the lights connected to the auxiliary cable.
8. Slide the switch to position two to power on the light bar. (This also powers the auxiliary lights)
9. The “STL” on the Supreme Control Box will light up when the switch box is turned on.
10. The LED display will show the pattern of the light bar that is currently flashing.
11. Use the Supreme control box to control the light bar and its functions.
12. See below pictures for further assistance.

